HOW TO CHANGE YOUR EMBOSSING WHEEL

IN SECONDS-



a. If Tapewriter comes equipped with a wheel screw, remove the screw with a screwdriver.

b. If Tapewriter comes equipped with a Quick-Change Pin, simply pull the Change Pin out.



Carefully slip wheel out of housing and place in folder or case to protect the die.

Now push the new Quick-Change Pin firmly into the housing. The Change Pin is designed for rapid interchanging of all your DYMO wheels . . . pull the Change Pin out. Slip wheel out/in. Push pin in to lock.

Slip new wheel into hous-

ing and align holes. (Slight

pressure and center-

ing a letter in window makes alignment easy.)



DYMO INDUSTRIES, INC. P.O. Box 1030, Berkeley 1, Calif.

Form No. 34 (Rev. 4) Printed in U.S.A.